# Paddle Wheel Flow Transmitter

588326 (46925-00)



LabVolt Series

Datasheet



## **Table of Contents**

General Description	3
List of Manuals	3
Table of Contents of the Manual(s)	3

© Festo Didactic 2

### **General Description**

The Paddle wheel Flow Transmitter provides a accurate measurement of the flow rate by inserting a paddle wheel into the flow stream. A sensor measures the velocity of the paddle wheel which is converted into a direct reading of the flow rate displayed on a remote digital display. The Paddle Wheel Flow Transmitter also features a 4-20 mA output signal.

### **List of Manuals**

Description	Manual number
Paddle Wheel Flow Transmitter (Workbook)	585139 (85998-00)
Paddle Wheel Flow Transmitter (Workbook (Instructor))	585140 (85998-10)

### Table of Contents of the Manual(s)

Paddle Wheel Flow Transmitter (Workbook) (585139 (85998-00))

• 1 Paddle Wheel Flow Transmitter

3 © Festo Didactic

Reflecting the commitment of Festo Didactic to high quality standards in product, design, development, production, installation, and service, our manufacturing and distribution facility has received the ISO 9001 certification.

Festo Didactic reserves the right to make product improvements at any time and without notice and is not responsible for typographical errors. Festo Didactic recognizes all product names used herein as trademarks or registered trademarks of their respective holders. © Festo Didactic Inc. 2025. All rights reserved.

#### **Festo Didactic SE**

Rechbergstrasse 3 73770 Denkendorf Germany

P. +49(0)711/3467-0 F. +49(0)711/347-54-88500

### **Festo Didactic Inc.**

607 Industrial Way West Eatontown, NJ 07724 United States

P. +1-732-938-2000 F. +1-732-774-8573

#### Festo Didactic Ltée/Ltd

675 rue du Carbone Québec QC G2N 2K7 Canada

P. +1-418-849-1000 F. +1-418-849-1666

### www.labvolt.com

www.festo-didactic.com

© Festo Didactic 4