

Mobile Workstation 579755 (8110-20)

FESTO

LabVolt Series

Datasheet



* The product images shown in this document are for illustration purposes; actual products may vary. Please refer to the Specifications section of each product/item for all details. Festo Didactic reserves the right to change product images and specifications at any time without notice.

Festo Didactic
en
11/2024

Table of Contents

General Description _____ 3

Module Installation _____ 3

Safety Padlock Bars _____ 3

Additional Information _____ 4

Manual _____ 4

Table of Contents of the Manual(s) _____ 4

Specifications _____ 4

General Description

The Mobile Workstation is a ready-for-use workstation that consists of two fully assembled modules: a Workstation mounted on a Mobile Storage Cabinet. Four rubber-tire swivel casters allow easy movement of the workstation in the laboratory classroom. The lower portion of the workstation serves as a storage cabinet with two hinged panels and a lock handle. Immediately above the storage cabinet is a pullout work surface with a scuff- and burn-resistant laminate finish. The upper portion of the workstation consists of three rows of compartments designed to house EMS modules. Two of these rows have full-height compartments while the other row has half-height compartments. Each row of full-height compartments can accommodate up to three full-size EMS modules or six half-size EMS modules, whereas the row of half-height compartments can accommodate up to three half-size EMS modules.

Module Installation

The EMS modules are guided into position along stainless steel guide rails. Separators between each bay of the workstation ensure perfect alignment of the EMS modules and allow their easy insertion in the workstation. A holding mechanism ensures that each EMS module stays in place once it is installed in a compartment of the workstation. Front-mounted push levers allow all EMS modules on a single row to be released for easy removal.



Safety Padlock Bars

Two safety padlock bars on the front of the workstation prevent students from removing EMS modules during laboratory exercises. The bars can be removed and locked to the side of the workstation when the safety lock is not necessary.



Additional Information

Six holes in the rear panel of the workstation allow connection to a power supply, as well as the connection of 2 kW machines to their interconnection modules. Assembly of the workstation before painting ensures that each EMS module in the workstation is correctly grounded.

Manual

Description

Manual number

Electric Power Technology Training Equipment (User Guide) _____ 584778 (38486-E0)

Table of Contents of the Manual(s)

Electric Power Technology Training Equipment (User Guide) (584778 (38486-E0))

- 1 General Safety Recommendations
- 2 System Power Requirements
- 3 Quick Start Installation Guide
- 4 Equipment Installation
- 5 Modules Handling, Installation, and Removal
- 6 Equipment Maintenance
- A Connection of the Power Supply to the AC Power Network
- B Description, Specifications, and Operation of the EMS Modules

Specifications

Parameter	Value
Physical Characteristics	
Intended Location	On the floor (stands on casters)
Dimensions (H x W x D)	1660 x 935 x 665 mm (65.4 x 36.8 x 26.2 in)
Net Weight	77.1 kg (170 lb)

Reflecting the commitment of Festo Didactic to high quality standards in product, design, development, production, installation, and service, our manufacturing and distribution facility has received the ISO 9001 certification.

Festo Didactic reserves the right to make product improvements at any time and without notice and is not responsible for typographical errors. Festo Didactic recognizes all product names used herein as trademarks or registered trademarks of their respective holders. © Festo Didactic Inc. 2024. All rights reserved.

Festo Didactic SE

Rechbergstrasse 3
73770 Denkendorf
Germany

P. +49(0)711/3467-0
F. +49(0)711/347-54-88500

Festo Didactic Inc.

607 Industrial Way West
Eatontown, NJ 07724
United States

P. +1-732-938-2000
F. +1-732-774-8573

Festo Didactic Ltée/Ltd

675 rue du Carbone
Québec QC G2N 2K7
Canada

P. +1-418-849-1000
F. +1-418-849-1666

www.labvolt.com

www.festo-didactic.com