

# Tabletop Workstation 579484 (8134-20)

**FESTO**

LabVolt Series

Datasheet



\* The product images shown in this document are for illustration purposes; actual products may vary. Please refer to the Specifications section of each product/item for all details. Festo Didactic reserves the right to change product images and specifications at any time without notice.

Festo Didactic  
en  
04/2024

## Table of Contents

General Description _____	3
Module Installation _____	3
Safety Padlock Bars _____	3
Additional Information _____	4
Manual _____	4
Table of Contents of the Manual(s) _____	4
Specifications _____	4

## General Description

The Workstation is a fully assembled workstation that serves the same purpose as the Mobile Workstation but has no storage cabinet or pull-out work surface. This workstation is intended for use on a bench (not supplied) and is fitted with rubber feet to protect the bench top. Alternatively, this workstation can be mounted on either a Mobile Storage Cabinet, to make a Mobile Workstation, or on a Mobile Base, to make a mobile workstation without storage cabinet. In that case, it is possible to mount and lock a second Workstation, on top of the first Workstation to double the space available for EMS modules.

The Workstation consists of three rows of compartments designed to house EMS modules. Two of these rows have full-height compartments while the other row has half-height compartments. Each row of full-height compartments can accommodate up to three full-size EMS modules or six half-size EMS modules whereas the row of half-height compartments can accommodate up to three half-size EMS modules.

## Module Installation

The EMS modules are guided into position along stainless steel guide rails. Separators between each bay of the workstation ensure perfect alignment of the EMS modules and allow their easy insertion in the workstation. A holding mechanism ensures that each EMS module stays in place once it is installed in a compartment of the workstation. Front-mounted push levers allow all EMS modules on a single row to be released for easy removal.



## Safety Padlock Bars

Two safety padlock bars on the front of the workstation prevent students from removing EMS modules during laboratory exercises. The bars can be removed and locked to the side of the workstation when the safety lock is not necessary.



## Additional Information

Six holes in the rear panel of the workstation allow connection to a power supply, as well as the connection of 2 kW machines to their interconnection modules. Assembly of the workstation before painting ensures that each EMS module in the workstation is correctly grounded.

## Manual

### Description

### Manual number

Electric Power Technology Training Equipment (User Guide) \_\_\_\_\_ 584778 (38486-E0)

## Table of Contents of the Manual(s)

### Electric Power Technology Training Equipment (User Guide) (584778 (38486-E0))

- 1 General Safety Recommendations
- 2 System Power Requirements
- 3 Quick Start Installation Guide
- 4 Equipment Installation
- 5 Modules Handling, Installation, and Removal
- 6 Equipment Maintenance
- A Connection of the Power Supply to the AC Power Network
- B Description, Specifications, and Operation of the EMS Modules

## Specifications

Parameter	Value
<b>Physical Characteristics</b>	
Intended Location	On a table able to support the weight of the workstation and installed equipment
Dimensions (H x W x D)	890 x 935 x 465 mm (35.0 x 36.8 x 18.3 in)
Net Weight	31.8 kg (70 lb)

Reflecting the commitment of Festo Didactic to high quality standards in product, design, development, production, installation, and service, our manufacturing and distribution facility has received the ISO 9001 certification.

Festo Didactic reserves the right to make product improvements at any time and without notice and is not responsible for typographical errors. Festo Didactic recognizes all product names used herein as trademarks or registered trademarks of their respective holders. © Festo Didactic Inc. 2024. All rights reserved.

**Festo Didactic SE**

Rechbergstrasse 3  
73770 Denkendorf  
Germany

P. +49(0)711/3467-0  
F. +49(0)711/347-54-88500

**Festo Didactic Inc.**

607 Industrial Way West  
Eatontown, NJ 07724  
United States

P. +1-732-938-2000  
F. +1-732-774-8573

**Festo Didactic Ltée/Ltd**

675 rue du Carbone  
Québec QC G2N 2K7  
Canada

P. +1-418-849-1000  
F. +1-418-849-1666

[www.labvolt.com](http://www.labvolt.com)

[www.festo-didactic.com](http://www.festo-didactic.com)